 **Iconsoft Phone Extension**
PhonEx v2

Copyright Notice © 2004-2009 Iconsoft. All rights reserved. Information in this manual is subject to change without notice and does not represent a commitment on the part of Iconsoft. All company and product names mentioned in the manual may be trademarks or registered trademarks of their respective owners.

1 Table of contents

1	Table of contents	2
2	Description	3
3	Installation / Removal	4
4	Registration	5
5	Today Plug-in	7
6	Favorites	9
7	Contact info	10
8	Calls.....	11
9	Contacts.....	12
10	Selecting photo and ringtone	13
11	Phonepad.....	14
12	Smart Dialing / Phonepad search	15
13	Incoming Call	16
14	Dialer	17
15	Installing Iconsoft PhonEx theme	18
16	Options	18
17	Technical Support.....	21

2 Description



Iconsoft Phone Extension or **PhonEx** is a new-generation software application, implementing a new type of user interface for managing the main telephone functions, built on the Iconsoft Mobile Engine.

PhonEx opens up new possibilities for convenient interaction, using simple touch, without a stylus, while retaining all the capabilities of a palmtop device on a Windows Mobile platform.

Main features in PhonEx:

- First and only fully new phone application in the world for Windows Mobile devices.
- Convenient intuitive interface
- Interaction using simple touch (without stylus)
- Multilanguage interface (English, Russian, German, and Spanish...).
- WM5, WM6.x support
- Today plug-in
- Photo contacts (including SIM contacts)
- Smart Dialing – quick contact search using Phonepad.
- Individual tune for calls (including SIM contacts)
- Expanded call history for each contact
- Favorites group
- Full-screen incoming call
- Slide to unlock screen
- Full-screen Dialer
- Speed Dial
- Contact filtering by category and by company
- Added capability to assign image and ringtone to entire category or company group
- Call filtering by type
- New and easy Phonepad
- Convenient contact search
- Personalization
- Landscape mode support
- Image library
- Broad options capability
- **and much more!**

3 Installation / Removal

Installation of Iconsoft PhonEx is a very simple process and takes less than five minutes to complete. The following installation guide will help you.

System Requirements

Iconsoft Phone Extension works with Windows Mobile 5.0 and Windows Mobile 6.x devices. Recommended screen resolution is 240 x 320 pixels, 240 x 400 pixels, 320 x 320 pixels, 480 x 640 pixels, 480 x 800 pixels. Devices without a touch screen and older platforms are not supported. Iconsoft Phone Extension will not install on these devices.

Installing PhonEx

After you have downloaded the PhonEx setup file, you should install it on your device. For successful installation, you will need to connect your device to a Windows desktop PC. To properly install PhonEx, you will also need [Microsoft ActiveSync](#) software.

When you run the PhonEx installer on your desktop PC, it will ask you to accept the license agreement and will start the installation program. You will NOT be prompted for the folder where you want the software to be installed.

NOTE

Microsoft ActiveSync works only with Windows XP SP2/SP3 or earlier versions. If you have Windows Vista, your synchronization settings will be managed through the Windows Mobile Device Center. Windows Mobile Device Center is available through the [Windows Mobile Device Center page](#).

Uninstalling

To remove the product from your device:

1. Go to **Start > Settings**
2. Open **System** and tap on **Remove Programs**
3. Select **Iconsoft Phone Extension** from the list and tap on the **Remove** button
4. Choose **Yes** to confirm removal

4 Registration

You will be able to use the **Iconsoft Phone Extension** during a trial version period of 15 days. If you have not registered **Iconsoft Phone Extension** within this time, you will need to do so before you can continue using it.

To purchase the program, visit our web site www.iconsoft.com

Note

To find out whether your copy of **PhonEx** is registered or how many days in the trial period are left go to **Phonepad > submenu > Options > About**.

If you officially purchased the program, you may register it in one of three ways:

1. Online registration (recommended)

This is the easiest and fastest way to register your copy of the program. This method is available if your device has Internet access. If your device does not have Internet access, you need to use the second or third registration methods.

- Launch the application and open the registration window **PhonEx > Phonepad > Submenu > Registration**.
- Choose the upper item – **Online registration (recommended)** and press **Next>**.
- In the new window enter the **email** address you used when purchasing the product.
- Press the **Register!** Button. If you indicated the correct info, a window will appear with a message on successful registration.
- Also you will get confirmation E-mail from Registration center.


2. Manual registration (Registration on the site)

This is a convenient way to register if your device does not have Internet access for online registration, but you have access to a PC with an Internet connection.

- Go to the **Registration Center** at www.iconsoft.com and choose the upper item **Product registration**.



Phonepad submenu



Registration window



- In the **Email** field indicate the email address you used when purchasing the product.
- In the **Product ID** field indicate the product number, which you can find in the window Product -> About.
- Click the **Send** button. If you indicated the correct info and registration is successful, you will receive a serial number which you will need to enter in the registration window of your device.
- Also you will get confirmation E-mail from Registration center.

After receiving the serial number

- Launch the application and open the registration window **PhonEx > Phonepad > Submenu > Registration**.
- Choose the item **Manual registration** and press **Next>**.
- In the new window enter the email address you used when purchasing the product and the serial number you got from the web site.
- Press the **Register!** button. If you indicated the correct info, a window will appear with a message on successful registration.

3. Registration by email


If online registration through the device or web site is not possible, you can register and obtain the serial number by email.

- Go to the **Registration Center** at www.iconsoft.com, choose the third item **Registration by email**, and follow the prompts.

Registration deactivation

If you need to install your copy of the program on a different device or if you performed a full reinstall of the system, you must first deactivate the previous installation of the program.

- When attempting to register your copy of the program again, you will be sent an email message requesting to confirm deactivation. You can also deactivate the previous registration through our web site.
- Go to the **Registration Center** at www.iconsoft.com and choose the second item **Deactivate product**.




<http://www.iconsoft.com>



5 Today Plug-in

The **PhonEx Today Plug-in** was designed especially for quick and easy access to the main **PhonEx** functions.

After installing **PhonEx**, you will immediately see the **PhonEx Today Plug-in** on your communicator screen.*

Missed calls and unread messages will be marked in **PhonEx Today Plug-in** as a round symbol.


To go to the **PhonEx** section of your choice, simply tap one of the menu buttons once.




To go to the second level menu for **Favorites**, **Calls** or **Phonepad**, press and hold the relevant button.




You will open the 5 upper contacts from the Favorites section. To call one of the contacts, simply press it.



Opens the list of recent calls. To call one of the contacts, simply press it.



PhonEx Today Plug-in



PhonEx Today Plug-in



Communications (press and hold)

Opens the second level menu that allows changing the phone status and to manage Bluetooth and Wi-Fi.



Phone on/off function



Bluetooth on/off function

Make this device visible to other devices



Bluetooth on



Wi-Fi on/off function




Changes the phone profile (7 modes – with sound, silent, vibration, sound with vibration, single ring, increasing sound, and sound after vibration).




Flight mode on/off function

 **Note**

**If after installing PhonEx you do not see the PhonEx Today Plug-in on your screen, make sure that the installation was performed correctly and that the PhonEx Today Plug-in is active in the Today settings.*



PhonEx Today Plug-in



PhonEx Today Plug-in

6 Favorites

Favorites - window shows popular contacts you chose. This allows to quickly find a popular contact without searching for it among others, which can take up much time.

To go to the **Contact Info** of a selected contact in the **Favorites** section, press the arrow sign to the right of the contact. This window shows the main contact information and allows editing (for more information see section 7 **Contact Info**).

Favorites submenu

To bring up the second level menu, press **Favorites** twice.

Details - takes you to the contact's details (also possible to press and hold the contact).

List/Grid - Changes the type of display for contacts, either a list or table.

Name - displays the contact name.

Send - sends a message or vCard.

Add - adds contact to Favorites.


Remove - removes contact from Favorites.

Up - raises the selected contact one slot up.


Down - lowers the selected contact one slot down.*

Note

To add a contact to **Favorites**, use the **Contacts** section. Removal from the **Favorites** group can be done from either section.



Favorites window



Favorites submenu

7 Contact info

In the **Contact Info** section, you can find all accessible information on a contact, an enlarged photo, telephone numbers, e-mail, web site and much more, as well as edit the contact and assign a photo and ringtone. These operations are also available for SIM card contacts, which was not possible before through WM.

Back - takes you to the Favorites or Contacts window.

Send - sends a message or vCard.

Calls - will take you to the calls history of the contact.

Change - opens the second level menu.

Contact info submenu

To bring up the second level menu, press the **Edit** button.


Photo - allows assigning a photo to a contact.

Ringtone - allows assigning a ringtone.

Favorite - marks the contact as a Favorite or removes it from the Favorite list if already included in it.

Contact - allows editing a contact.


Delete - deletes the contact (with confirmation).

 **Make Main** - makes the number the main one. When the contact is called, by default the number marked as main will be dialed.

Copy - copies the number to clipboard.

Note

If a photo or ringtone is already assigned, the program will ask you to first remove it (*physically a photo or ringtone file is not deleted and will always remain in the device memory without changes*).






Contact Info



Contact Info submenu

8 Calls

The **Calls** section reflects the entire detailed calls history. Calls are sorted by time and grouped by contact. The last calls are shown at the top of the list. All calls have a symbol designating the type of call.

-  – incoming
-  – outgoing
-  – missed

Calls submenu

To bring up the second level menu, press the **Calls** button a second time.

Missed - displays only missed calls.

By caller - sorts by caller.

By date - sorts by date.

Send - sends message or vCard.

Save - allows saving the number in the contacts or creating a new one.

Delete - deletes the contact from the calls list (with confirmation).

Delete All - clears the entire calls list (with confirmation).

Statistic - shows all statistics for calls.

To see the full calls history for a contact, go to the **Calls History** section.

Calls History


To view the Calls History, press the contact you want and then press the arrow on the right. In this section you will see the call history for the particular contact, as well as the call status and its time and duration.

Back - returns you to the **Calls** section.


Send - sends message or vCard.

Details - takes you to the Contact Info window of this contact.


Change - opens the second level menu.



Calls



Calls submenu



Calls History

9 Contacts

The **Contacts** section shows all the contacts on your device. Contacts marked with the SIM symbol are stored on your SIM card (these contacts can be hidden or displayed by adjusting the relevant options in the **PhonEx** settings). All other symbols before the contact number indicate the type of telephone to which this number is assigned. On the right side of the screen you will see the ABC scroller which allows you to quickly move through the list of contacts by simply touching the letter you need or by sliding your finger along the whole list.

From the **Contacts** section (by pressing the arrow to the right of the selected contact) you can go to the **Contact Info** window. This window displays the main information on a contact and also allows editing the contact (for more information see section 7 **Contact Info**).

Contacts submenu

To use the second level menu, press the **Contact** button a second time.

ABC is a filter by first letter. Using this filter you can leave in your list only the contacts that start with a particular letter.

Company - filters by companies.

Category filters by categories. This is a powerful filter tool with which you can filter your contacts by categories you need, as well as assign a background or ringtone for the entire group of contacts.


Send - sends message or vCard.

New - creates a new contact.


Delete - deletes the selected contact (with confirmation).

Note

Holding the **Contacts** button longer than one second brings out the Contacts Filter.




Contacts window



Contacts submenu



Filter by category



10 Selecting photo and ringtone

To have a photo be displayed for a particular contact or to have a specific ringtone sound during a call, they need to be assigned. Doing this in **PhonEx** is easy.

1. Go to the **Contact Info** section.
2. Press the **Change** button to open the second level menu. You will see the **Photo** and **Ringtone** buttons.
3. Press one of the buttons and you will see the **PhonEx File Explorer** which is also built on the **Iconsoft Mobile Engine** and can be navigated with just your finger, without a stylus.
4. Find the file you need and select it.

If you choose an audio file for the ringtone the **Play** button will appear on the right – press it to hear the selected file.

If you choose an image for the contact, the **PhonEx Image Editor** will open up, where you can edit the image (rotate or change the boundaries).

File Explorer

Cancel - cancels the file search.

Up.. - goes up one level.

Media - moves you to the **PhonEx/Media** folder.

Open - opens the folder or file. (Also possible to double-tap the folder or file.)

Image Editor

Cancel - cancels assigning the photo.

90° CCW - rotates the image 90 degrees counterclockwise.

90° CW - rotates the image 90 degrees clockwise.



PhonEx File Explorer



PhonEx File Explorer

Apply - assigns the photo to the contact.
 In the center of the window you will see a rectangular highlighted area. This will be the actual visible area of the assigned photo. You can change the borders by pressing and dragging the corner markers. You can move the entire area by pressing in the center of the rectangle and dragging it to where you need.

 **Note**

If a photo or ringtone are already assigned, the program will ask you to first remove it (*physically a photo or ringtone file is not deleted and will always remain in the device memory without changes*).




Image Editor

11 Phonepad

The **Phonepad** section has a full-screen telephone keypad. The upper part contains a display that shows the dialed number or the last contact made. The right side of the screen has additional buttons.



Erase - deletes the last digit entered.



Save - saves the dialed contact in the Contacts.



Call - calls the dialed number or sends a service call.

Phonepad submenu

Pressing the **Phonepad** button a second time will bring up the second level menu.

WM phone - switches to standard Windows Mobile phone (for example, for making a video call).

Copy - copies number to clipboard.

Paste - inserts number from clipboard.

Send - sends message or vCard.

Options - opens the PhonEx settings

Registration - opens the registration dialog. (If the program is registered, the button is disabled.)



Phonepad




Phonepad submenu

Speed Dial - allows placing a call by pressing a reduced number of keys.

Exit - closes PhonEx.

 **Note**

Holding the **Exit** button longer than one second closes the application completely, restoring the full functions of the standard Windows Mobile telephone.




12 Smart Dialing / Phonepad search

When dialing a number or a contact name in **Phonepad**, the application will automatically search for a matching sequence of numbers and letters and will bring up only the contacts that match.

To see the contacts found press the upper bar of Phonepad, where the number is shown and the list with the found matches will be shown. Pressing the bar a second time will take you back to Phonepad.

From the **Smart Dialing** list you can also go to the **Contact Info** window.



Smart Dialing

12 Speed Dial

Speed Dial is a function available on many telephone systems allowing the user to place calls by pressing a reduced number of keys. This function is particularly useful for phone users who dial certain numbers on a regular basis.

When the **Speed Dial** button is pressed, each button will have a symbol displayed above it showing whether it is available or not for assigning a telephone number to it.

The whole interface has been thought out in detail and is intuitively understandable so that grasping the **Speed Dial** functions will only take you several seconds.



Speed Dial editing

13 Incoming Call

PhonEx has a full-screen incoming call window.

Upper part of the screen shows the contact's name, type and telephone number. Central part displays the photo assigned to the contact, and the lower part of the screen has buttons for accepting or declining a call.

If the screen lock option is on, you will need to use the slider to unlock it during an incoming call. This is done to prevent accidental pressing of the incoming call buttons.

Slide to unlock.

Press the slider at the bottom of the screen and move it toward the left extreme or the right extreme, depending on the desired result.

To answer a call, press the green **Answer** button. You will then see the **Dialer** screen.

If you press the red **Decline** button, the call will be dropped and will be listed in the calls history as a missed call.

Options menu

Pressing the central button in form of the PhonEx logo turns off the ringtone sound and opens an additional menu.

Speaker - answers the call with the loudspeaker turned on.

Silent - turns off the ringtone for incoming calls.


Send - reply to a call using a message.

Call Back - declines the call and immediately dials the person that called.

Pressing the central button a second time will take you back to the menu with **Answer** and **Decline** buttons.



Incoming Call/Slide to unlock



Incoming Call/Options menu

14 Dialer

PhonEx has a full-screen and fully functional **Dialer**. The **Dialer** window always appears when a number is dialed and during a call.

Upper part of the **Dialer** window contains an information screen with an enlarged contact photo (if available), the contact name, status and call duration.

Lower part has the **End call** button.

The middle section contains additional navigation buttons.

Speaker - turns on the loudspeaker.

Mute - turns off the microphone.

Contacts - moves you to the contact list.

Hold - will hold the call.

Phonepad - switches to the screen dialer pad.


Notes - quick access to your notes.

Conference - button appears when two incoming call calls are on the line. Pressing the Conference button allows having a three-way conversation.

During a call on the second line, you will see both contacts simultaneously, as well as the call status. Along with the second connection, the **Swap** button appears, allowing you to switch between calls.

 **Note**


The Dialer shown on the screenshot is the Dialer for GSM networks. For CDMA phones the Dialer may look different from what is shown here.



Dialer




Dialer



15 Installing the Iconsoft PhonEx theme

1. Download the appropriate .CAB installation file.
2. Copy the CAB file onto your Pocket PC device.
3. If your device is connected to the Internet, you can skip the above steps and download the .CAB file directly to your Pocket PC.
4. Run the .CAB file on your device.
5. Follow the instructions on the screen of your device. The theme must be installed to the same place that PhonEx is installed into.
6. To change the theme (including to apply the newly installed theme) go to **Phonepad->Options->General->Use PhonEx theme**.



Options/General


16 Options

To enter the **PhonEx** options, go to **Phonepad > submenu > Options**.

General

This tab contains the general settings.


Use PhonEx theme allows selecting the graphical PhonEx theme. After installation, two themes are available: Default (black) and Default (aquarel).



Options/General

Phone


This window has the main **PhonEx** settings.



Options/PhonEx

Contacts


This window allows adjusting the settings and format for displaying the contact list.



Options/Contacts

Formats


This window allows assigning the format for displaying **PhonEx** telephone numbers.



Options/Format

SMS


In this window you can type in template SMS texts.



Options/SMS

Today

In this window you can set up the way Today plug-in looks.




Options/Today

Fonts

This tab allows setting the fonts for all the PhonEx elements

 **Note**

By default, all fonts are chosen and set for proper display of the main types of information. You should not change the font setting unless there is a real need.



Options/Fonts

About

This window contains information about the product, the program version and Product ID.

**Options/About****17 Technical Support**

Before contacting the Iconsoft technical support, please read the instruction manual, as well as the **PhonEx FAQ**. You may find the answer to your question there.

To contact technical support, go to the support web page at www.Iconsoft.com and fill out a form.

Please include the following information to help us identify the problem:

1. The type of the device you are using.
2. The software name and version number. Open **PhonEx** and select **Phonepad > submenu > About...** to view the software name and version number (example: PhonEx, version 2.0).
3. Any error messages that accompany the problem.
4. A brief description of how we can recreate the error.
5. Your name and e-mail address.